


Position Bench

Assembly guide

Components


Place the components on a blanket to avoid scratches on the floor and on the product.



Video assembly guide


Step 1

Place the seat bottom up on any larger table. Let the side with shortest gap between the rim and the seat face outwards. To protect the surface from scratches lay a piece of textile or cardboard under the seat.




Step 2

Place the leg frames above the bushings. Place the leg components with the screw holes facing inwards. Using the included Allen key (D), mount the screws (A) in the seat. Tighten the screws properly, though without fully tightening them.




Step 3

Place the two steel parts (F) on the seat and mount the short screws (B). Tighten the screws with a large flat-headed screwdriver.




Step 4

Place the two dowels (C) in the legs.



Step 5

Place the backrest in the two dowels. Mount the two long screws(E) in the backrest. Tighten the screws with a large flat-headed screwdriver.



Step 6

The product is now assembled.

Important: Screws may loosen over time due to use or vibration. Check and tighten them regularly to maintain stability. We recommend re-tightening (but not over-tightening) the screws approximately every six months. This helps your furniture stay stable and maintain its quality for years to come.

