

VINCENT SHEPPARD



Wicked collection

Product data sheet

Wicked collection



WICKED DINING ARMCHAIR



WICKED LOUNGE CHAIR



WICKED LOUNGE SOFA 2S



WICKED LOUNGE SOFA 3S



WICKED SUNLOUNGER



WICKED DINING TABLE



WICKED SIDE TABLE



WICKED COFFEE TABLE

WICKED

frame	aluminium
frame finish	powdercoated in black, white or terracotta
seat	HDPE wicker
seat color	taupe or natural
top/finish	untreated teak
glides	black nylon

CUSHION

foam	dining chair:	2 cm polyether foam
	lounge chair / sofa:	10 cm quick dry foam + padding
	sunlounger:	10 cm quick dry foam seat + padding
removable fabrics	3 cm quick dry foam back + padding	
	yes	
	see fabric data sheet for more info	

COLOURS

Frame / seat















Base



Top



DIMENSIONS



IN THIS COLLECTION

WICKED	ITEM CODE	FINISH	PACKAGE DIMENSION (cm/inch)	CBM (m ³ /ft ³)	WEIGHT (kg/lb)
dining chair	GD185A007S021	black / taupe	117 x 62 x 58	46 x 24 x 23	0,42 14,86
	GD185A008S024	white / natural			7,37 16,25
	GD185A028S053	terracotta / natural			
lounge chair	GC037A007S021	black / taupe	80 x 100 x 80	31 x 39 x 31	0,64 22,60
	GC037A008S024	white / natural			9 19,84
	GC037A028S053	terracotta / natural			
lounge sofa 2S	GC040A007S021	black / taupe	76 x 164 x 86	30 x 65 x 34	1,07 37,85
	GC040A008S024	white / natural			22 48,50
	GC040A028S053	terracotta / natural			
lounge sofa 3S	GC036A007S021	black / taupe	80 x 210 x 80	31 x 83 x 31	1,28 47,46
	GC036A008S024	white / natural			41 90,39
	GC036A028S053	terracotta / natural			
sunlounger	GC175A028S053	terracotta / natural	227 x 125 x 41	89 x 49 x 16	1,16 41,19
dining table 200	GT166A007W002	black / untreated teak	15 x 204 x 95	6 x 80 x 37	0,29 10,21
	GT166A008W002	white / untreated teak			48,15 106,15
dining table 250	GT167A007W002	black / untreated teak	15 x 254 x 95	6 x 100 x 37	0,09 12,71
	GT167A008W002	white / untreated teak			56,8 125,22
side table	GT070A007W002	black / untreated teak	44 x 46 x 46	17,3 x 18 x 18	0,09 3,2
	GT070A008W002	white / untreated teak			5,5 12,13
	GT070A028W002	terracotta / untreated tea			
coffee table	GT071A007W002	black / untreated teak	42 x 132 x 63	17 x 52 x 25	0,35 12,33
	GT071A008W002	white / untreated teak			19,1 42,11
	GT071A008W028	terracotta / untreated teak			

MAINTENANCE AND CARE

STAINED TEAK

FOR DAILY CARE

Use a moist towel or sponge with a mild solution of water and natural, non-aggressive soap.

FOR STUBBORN STAINS

If your furniture is stained, consider one of the following options:

- **Grease spots have appeared on the furniture**

This is a natural feature of the wood and grease spots should gradually disappear after being exposed to sunlight. However, should you wish to remove these blemishes, we recommend using a degreasing agent and gentle scrubbing with a brush. Rinse off with clean water.

- **The furniture has developed mildew spots or black blemishes**

This is usually the result of rainwater or sometimes sap dripping from the leaves of trees onto the wood leaving dark marks and spots. Ideally, we recommend the furniture is not placed under trees. However, these marks can be removed by lightly sanding with fine sandpaper.

- **You spilled wine or something else leaving persistent stains**

For wine and other stains, we recommend using a weak solution of bleach and water combined with a dishwashing agent to wipe the area clean.

CERAMIC

If you're looking for a material which requires little to no maintenance, yet offers maximum resistance, you would do well to involve ceramic. The material preserves the natural look of stone and offers top of the chart convenience. Cleaning the table with water and mild soap will do the trick!

POLYPROPYLENE ROPE

Another material used for our all-weather furniture, is rope. Our rope is made of polypropylene fibres or acrylic. Just like our other synthetic materials, the rope is designed to withstand any weather condition and can be left outside all year long.

For maintaining your rope furniture, we recommend using a fabric and upholstery protector to give optimal stain resistance.

To clean spots on the rope, we suggest applying a mist of soapy water with a spray bottle and then work the solution into the rope with a soft cloth by patting or rubbing lightly. Rinse the solution thoroughly and then blot excess moisture from the rope using a soft cloth and allow air-drying.

Never use a high-pressure hose on polypropylene rope.