


- INSTRUCTION MANUAL -

PACK CHAIR SEAT COVER




DESIGN BY JASPER MORRISON

HAY

PACK CHAIR SEAT COVER

Design by Jasper Morrison









Do not place the seat cover in a washing machine.
Machine washing may damage the cover.
Clean by hand or dry clean only.

Instruction Manual

Follow the illustrated guide on the opposite side of this page along with this written guide.

- 1 Place the cover on top of the seat. Align it as shown in the drawing, ensuring it fits properly around the legs.
- 2 Hold the seat cover in place while turning the chair upside down onto a suitable surface, such as a tabletop. Begin with the front and back sides, then finish with the sides.



- 3 Insert the black profile of the cover into the groove along the underside of the seat. Start at one corner and work your way across.
- 4 Make sure the black trim is fully inserted into the groove all the way around. Once it is properly fitted, turn the chair upright.
- 5 To finish, ensure the cover is properly positioned and fits correctly around the legs.
- 6 SEAT COVER DISASSEMBLY
Locate the wire loops in two corners of the cover. Pull them upwards to release the black profile from the groove. Then remove the rest of the cover.

Our Care & Maintenance offers guidance for optimal maintenance of your HAY product. It includes advice and instructions on cleaning and caring for specific materials to prolong the life of your furniture.



Please find our Care & Maintenance guide by scanning the QR code above.



You can find more relevant information on Pack Chair by scanning the QR code.

You can also find the same information at hay.dk/downloads

Havnen 3 8700 Horsens Denmark
+45 3164 6000 / hay@hay.com

18/03/2026

HAY

